

ADAPTEC AC1-232XD TROUBLESHOOTING CHECKLIST

- **Gets a 1790 at boot:**
 - A 1790 Error is normally caused by a bad floppy disk or an unformatted drive. Just press F1 to continue.
 - **Long boot time:**
 - Some PC AT systems may not boot if the hard drive is not formatted. Try to format the hard drive even though it may continue to retry booting to the hard drive to allow this re-formatting to continue for up to two minutes before the system will boot up to continue for up to two minutes before to Debug and format the floppy drive. Then you can proceed to the next step.
 - **Can't read floppy:**
 - Check floppy cable. **Do not use a (ACB-2322D) only:**
 - Be sure that Pin 1 on the floppy cable goes to both floppy drives. Be sure that Pin 1 on the controller is connected to Pin 1 of the drive. If only one of the controllers is connected to Pin 1 of the drive, the twisted cable wires being used, only the last connector on 16 twisted cables should be used. A floppy cable has wires 10-16 twisted between the two drive connectors.
 - **Recal error, or no disk:**
 - Check the drive's drive controller.
 - Check the drive's jumper on the hard disk drive; be sure that it is correctly placed. Jumper for the hard disk drive; be sure that it is correctly placed for the type of cable you are using.
 - Check hard drive. Set for the type of cable you are using.
 - Drive 1, and J4 goes to Drive 0, J2 goes to Drive 1, and J4 goes to Drive 1. Be sure that Pin 1 on the controller is connected to Pin 1 of the drive. If only one drive is being used, only the correct Pin 1 of the drive. If only one drive is being used, only the correct Pin 1 should be used.
 - **Incorrect drive parameter:**
 - ESDI drives have jumpers for number of sectors per track and for bytes per sector. Check the number of sectors per track and your drive vendor's also for hard or soft sectoring. Consult user soft sectoring for proper settings of these jumpers. Do not use soft sectoring for proper settings of these jumpers. Do not use soft sectoring for proper settings of these jumpers.
 - **Misc. errors, or no disk:**
 - Check that the controller's jumper is set correctly.
 - **Excessive defect:**
 - Make sure the drive is ESDI certified. Check with the drive manufacturer.
 - **Won't boot to C:**
 - Check to see that the SETUP program and CMOS RAM show drive type 1 is set.
 - **Intermittent operation:**
 - Check that the battery is good on each drive is set properly.
 - Check that the power supply can support the added current required by the drive. Make sure that the +5V and +12V voltages are correct. Consult the drive vendor for the correct drive power requirements.
 - **If none of the above:**
 - **out components:**
 - Replace the cable with a known-good cable.
 - Swap the drive with a known-good drive.
 - Swap the 232XD controller with another 232XD controller.
 - **Adaptec maintenance:**
 - Call (408) 945-7727 for a bulletin board for information and questions.

FCC CERTIFICATION

This equipment generates radio frequency energy and if not installed and used in accordance with the manufacturer's instructions, it may cause interference with radio and television reception. It has been type tested and found to comply with the limits for a Class B computing device in accordance with the specifications in Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular situation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient the receiver.
- Relocate the computer away from the receiver.
- Move the computer to a different outlet so that computer and receiver are on different outlets.
- Plug the computer into a power conditioner.
- If necessary, the user should consult the dealer or an experienced radio/television technician for additional suggestions. The user may find the following booklet prepared by the Federal Communications Commission helpful: "Resolving Radio-TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402, available from the GPO, 5010 Lippincott Avenue, Springfield, VA 22151-4302, Stock No. 004-000-000.

COPYRIGHT

© Copyright 1989 by Adaptec, Inc. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written consent of Adaptec, Inc., 691 South Milpitas Blvd., Milpitas, California 95035.


FIVE YEAR LIMITED LIFE-TIME WARRANTY

The Buyer that the products to be delivered under this warranty are free from defects in material and workmanship under normal use and service. Seller's obligations under this Warranty are limited, in no event, to repairing or (ii) repairing or (iii) giving credit for, any such products which, within five (5) years from date of shipment, are returned to the Seller in accordance with the terms of this warranty. ANY OTHER WARRANTY IS EXPRESSLY EXCLUDED. THE WARRANTY IS LIMITED TO THE SALE OF THE SAID ARTICLES. ANY OTHER LIABILITY, INCLUDING THE LIABILITY OF THE SELLER, SHALL BE LIMITED TO THE SALE OF THE SAID ARTICLES. ANY OTHER LIABILITY, INCLUDING THE LIABILITY OF THE SELLER, SHALL BE LIMITED TO THE SALE OF THE SAID ARTICLES. ANY OTHER LIABILITY, INCLUDING THE LIABILITY OF THE SELLER, SHALL BE LIMITED TO THE SALE OF THE SAID ARTICLES. ANY OTHER LIABILITY, INCLUDING THE LIABILITY OF THE SELLER, SHALL BE LIMITED TO THE SALE OF THE SAID ARTICLES.

CHANGES

The material in this guide is subject to change without notice. Adaptec reserves the right to make changes in the product design without reservation of information or other technical support. If you require further information or other technical support, please contact your authorized dealer.

691 South Milpitas Blvd., Milpitas, California 95035
 Adaptec, 691 South Milpitas Blvd., Milpitas, California 95035




Adaptec
 232XD
 User's Guide

7727

QUICK INSTALLATION

1. Install controller and drives into cable them together. Run a floppy floppy drives (ACB-2322D) on the END of the cable goes to hard drive cable from J4 and connect one 20-pin cable from J5 to the first hard drive, and from J2 to the second hard drive (if installed).
2. Run your PC AT "SETUP" and set type 1.
3. Boot to DOS, and run DEBUG.
4. Type in : A > DEBUG <CR> -G=C800:5 <CR>
5. The Adaptec format menu will
6. Choose: 1 - to primary-format cylinders from the drive. The number of heads and cylinders from the drive. The number of cylinders will also be read in.
7. Now just keep hitting <CR> (to
8. After format is complete, Choose program * (Or 2 - to primary for
9. Now you are ready to install your software. Go to DOS FDISK and STOR, DISK MANAGER, SCO XE

*Note: If you are using DOS and you more than 1024 cylinders, select enable 63-sector translation. OS/2, UNIX, etc. then install your operating system.



| CONNECTORS |
|-------------------------------|
| J5 - FLOPPY DRIVE |
| J3 - HARD DRIVE 0. DATA CABLE |
| J2 - HARD DRIVE 1. DATA CABLE |
| J4 - HARD DRIVE CONTROL CABLE |
| J1 - DRIVE ACTIVITY LIGHT |

* = as shipped
 Out = No jumper installed
 In = Jumper installed

| JUMPERS |
|--|
| J10-1 HARD DISK PORT ADDRESS
*Out = 1F0-1F7
In = 170-177 |
| J10-2 FLOPPY DISK PORT ADDRESS
*Out = 3F0-3F7
In = 370-377 |
| J10-3 FLOPPY DISK DISABLE
*Out = Floppy enabled
In = Floppy disabled |
| J11-1 FLOPPY DRIVE SPEED
*Out = Single speed
In = Dual speed |
| J12 BIOS ADDRESS |
| *C8000 out out out |
| CC000 in out out |
| D0000 out in out |
| D4000 in in out |
| Disabled out out in |
| D8000 in out in |
| DC000 out in in |
| J13 *1-2 IRQ 14
2-3 IRQ 15 |

| SOFTWARE OPTION JUM |
|---|
| J7-1 NOT USED |
| J7-2 LOGICAL DRIVE SPL
*Out = drive uses ph
parameters
In = Drive 0 is split int
logical drives,
(if over 1024 cylind |
| J7-3 RESERVED |
| J7-4 NOT USED |
| J7-5 READ AHEAD CACH
*Out = Enabled
In = No Read Ahead
performed. |
| J7-6 RESERVED |
| J7-7 RESERVED |