

Readme for DS-XG NT4.0 Driver ver. 4.00.1228

Because this driver has various functions depending on the device you use, you may need a customization on the driver.

To make a customization, please follow the steps below:

1. If you have already installed a DS-XG driver, please remove "Audio for YAMAHA DS-XG Audio Driver" from Control Panel/Multimedia/Devices/Audio Devices first. Then restart the system.
2. Go into an appropriate directory under ¥Custtool. (There should be ydsxg.exe and ydsxg.cst in the directory.

¥Custtool

¥DS-1E -> For YMF754(DS-1E)

¥2ch -> For generic 2ch system

¥Generic 4ch -> For generic 4ch system with 2 AC97 CODECs

¥STAC9708_1 -> For STAC9708 4ch system which has separate Jack for Rear output.

¥STAC9708_2 -> For STAC9708 4ch system which uses GPIO2 to switch between Line in/Rear output.

¥DS-1S -> For YMF754(DS-1S)

¥2ch -> For generic 2ch system

¥Generic 4ch -> For generic 4ch system with 2 AC97 CODECs

¥STAC9708_1 -> For STAC9708 4ch system which has separate Jack for Rear output.

¥STAC9708_2 -> For STAC9708 4ch system which uses GPIO2 to switch between Line in/Rear output.

3. Execute ydsxg.exe by double-clicking on it from the Windows Explorer.
4. When you see a "Welcome" dialog box, click "Next".
5. You will see a message saying "The Setup program for the DS-XG/WindowsNT Driver is ready to complete." Click "Finish".
6. You will see a message saying "Customizing is success.". Click "OK".
7. Install the driver following the standard procedure.

Note

(1) Customization can be done after the driver is installed. However, the default values of the mixer controls cannot be customized in this case.

(2) If you need different customization, please ask your rep or your contact at Yamaha.