IBM ®   # Technical Update

New information about your Netfinity 5000

This Technical Update contains the following new information about your Netfinity 5000 server:

- RAID microcode update
- S3 video driver update

RAID microcode update

You must upgrade your RAID adapter microcode prior to installing the operating system on your Netfinity server if you have one of the following adapters installed:

- IBM ServeRAID-3H Ultra2 SCSI Adapter with the IBM ServeRAID-3H 32 MB/Battery-Backup Cache: use the microcode version 3.11 or later.
- IBM ServeRAID II Ultra SCSI Adapter with the IBM ServeRAID II 8 MB/Battery-Backup Cache: use the microcode version 2.88 or later.

To access this microcode, go to the IBM web site at www.pc.ibm.com/support

S3 video driver update

If you plan to use Microsoft® Windows NT Server® 4.0, obtain and install the latest version of the S3 video device driver from the World Wide Web.

1. Access the IBM Web site at:

   `http://www.pc.ibm.com/us/netfinity`

2. Select **Server support**, **Netfinity 5000**, and **Downloadable files**.

37L6972

Printed in the U.S.A.

IBM and Netfinity are trademarks of the IBM Corporation.

Microsoft, and NT Server are trademarks or registered trademarks of Microsoft Corporation.

Other company, product, and service names may be trademarks or service marks of others.